




# 1.52 Exploded View



The air chamber & safety valve are turned here 180° for illustration only

N.B. The self-locking nut in the suction valve should only be used once. Please keep this in mind when ordering spare parts!

When ordering spare parts, please state item number and code number of the part required as well as the pump model and year of construction which can be found on the name plate.